


Resurrecting the Soul of Music



TUBE INSTALLATION GUIDE

Top View



POSITION	VALVE	TYPE	Base	EQUIVALENT
V1	6J5 (G or GT)	Single Triode Input	Octal	6J5 Family
V2	6V6 (G or GT)	Triode Connected Tetrode Driver	Octal	6V6 Family
V3	2A3	DHT Power Output	UX4	2A3 Family
V4	5U4 (G or GB)	Double Diode Rectifier	Octal	***
V5	5U4 (G or GB)	Double Diode Rectifier	Octal	***

Installation

- Do not insert/remove tubes while the device is powered on.
- Wear gloves to avoid unwanted marks on the tubes
- Insert the corresponding tube into the socket until they firmly sit inside. Please take special care of the correct orientation when inserting the tubes.
- Certain tubes come with a location notch at their base that match the socket.

