


Resurrecting the Soul of Music



TUBE INSTALLATION GUIDE



Top View



| POSITION | VALVE | ТҮРЕ | Base | EQUIVALENT |
|----------|---------------|------------------------------------|-------|-------------|
| V1 | 6J5 (G or GT) | Single Triode Input | Octal | 6J5 Family |
| V2 | KT66 | Triode Connected Tetrode | Octal | KT66 Family |
| V3 | KT66 | Triode Connected Tetrode | Octal | KT66 Family |
| V4 | 5U4 (G or GB) | Double Diode Rectifier | Octal | *** |
| V5 | 6V6 (G or GT) | Triode Connected Tetrode Driver | Octal | 6V6 Family |

WARNING: V5 is a valve rectifier responsible for the biasing of V2 & V3. Do not operate the amplifier without the V5 in place as this can cause serious damage to the amplifier. Only replace V5 for the same type of rectifier and check the bias before operation.

Installation

- Do not insert/remove tubes while the device is **powered on**.
- Wear gloves to avoid unwanted marks on the tubes
- Insert the corresponding tube into the socket until they firmly sit inside. Please take special care of the correct orientation when inserting the tubes.
- Certain tubes come with a location notch at their base that match the socket.

