




Resurrecting the Soul of Music

DAC IV

Digital To Analogue Converter

TUBE INSTALLATION GUIDE

Top View




POSITION	VALVE	TYPE	EQUIVALENT
V1	5U4	Octal	5U4 Family
V2	6V6	Octal	6V6 Family
V3	6V6	Octal	6V6 Family
V4	6J5	Octal	6SJ7 Family
V5	6J5	Octal	6SJ7 Family

WARNING: V5 is a valve rectifier responsible for the biasing of V2 & V3. Do not operate the amplifier without the V5 in place as this can cause serious damage to the amplifier. Only replace V5 for the same type of rectifier and check the bias before operation.

WARNING: Please ensure that the valves are correctly inserted into the socket. Incorrect orientation can cause significant damage to the unit. Please match the pins with the socket correctly.

Installation

- Do not insert/remove tubes while the device is **powered on**.
- Wear gloves to avoid unwanted marks on the tubes
- Insert the corresponding tube into the socket until they firmly sit inside.
- Certain tubes come with a location notch at their base that match the socket.



Octal Type