




Resurrecting the Soul of Music

DAC V

Digital To Analogue Converter

TUBE INSTALLATION GUIDE

Top View




POSITION	VALVE	TYPE	EQUIVALENT
V1	5U4G	Octal	5U4/5U4G Family
V2	6J5	Octal	6J5 Family
V3	6J5	Octal	6J5 Family
V4	45	UX4	45 Family
V5	45	UX4	45 Family

WARNING: Do not operate the DAC without the V1 in place as this can cause serious damage to the DAC. Only replace V1 for the same type of rectifier and check the bias before operation.

WARNING: Please ensure that the valves are correctly inserted into the socket. Incorrect orientation can cause significant damage to the unit. Please match the pins with the socket correctly.

Installation

- Do not insert/remove tubes while the device is **powered on**.
- Wear gloves to avoid unwanted marks on the tubes
- Insert the corresponding tube into the socket until they firmly sit inside.
- Certain tubes come with a location notch at their base that match the socket.



Location Notch

